

Art.: 12039640
12039641

DE | Montageanleitung für Waschbecken

EN | Assembly instruction for washbasin

FR | Notice de montage pour lavabo

IT | Istruzioni per il montaggio del lavabo

NL | Montage-instructies voor wastafel

SE | Montering instruktioner för tvättställ

CZ | Montážní instrukce pro umyvadlo


SK | Montážna príručka pre umývadlo

RO | Instrucțiuni de asamblare pentru chiuvetă

PL | Instrukcja montażu umywalki


DE | WERKZEUGE

SE | VERKTYG




EN | TOOLS

CZ | NÁŘADÍ




FR | OUTILS

SK | NÁSTROJE





IT | STRUMENTI

RO | UNELTE




NL | GEREEDSCHAP


PL | NARZĘDZIA




1




2




3




4




5




6



7



8



9

Art.: 12039640
12039641

DE | Für die Wandmontage

EN | For wall-hung installation

FR | Pour l'installation murale suspendue

IT | Per l'installazione sospesa a parete

NL | Voor wandmontage

SE | För vägghängande installation

CZ | Pro zavěšenou instalaci na zeď

SK | Pre inštaláciu zavesenú na stenu

RO | Pentru instalarea suspendată pe perete

PL | Do instalacji wiszącej na ścianie

